

ITS 323 –MID TERM CHEAT SHEET

The following contains some important concepts and equations that we have learnt in ITS 323 up until the mid term. **This is not everything** – there are other important topics that are covered in lectures but not included in this handout.

1 Basic Maths

1.1 Logarithms

$$a = \log_n(b)$$

$$n^a = b$$

$$\log(xy) = \log(x) + \log(y)$$

$$\log(x/y) = \log(x) - \log(y)$$

$$10^x \times 10^y = 10^{(x+y)}$$

$$10^x / 10^y = 10^{(x-y)}$$

$$\log_2(x) = \frac{\log_{10}(x)}{\log_{10}(2)}$$

1.2 Units

G: 1,000,000,000 or 10^9

M: 1,000,000 or 10^6

K (or k): 1,000 or 10^3

m: 0.001 or 10^{-3}

μ : 0.000001 or 10^{-6}

n: 0.000000001 or 10^{-9}

b: bit

B: byte = 8 bits

1.3 Power and Decibels

Decibel gain, $G_{dB} = 10 \log_{10}(P_{out}/P_{in})$

$Power_{dBW} = 10 \log(Power_W / 1W)$

$Power_{dBm} = 10 \log(Power_{mW} / 1mW)$

2 Protocol Architectures

2.1 Layered Models

<i>OSI (7)</i>	<i>Internet (5)</i>
Application	Application
Presentation	--
Session	--
Transport	Transport
Network	Network
Data Link	Data Link
Physical	Physical

2.2 Address Types

Application (or user-specific), e.g. www.google.com

Transport or ports, e.g. 80 for web servers

Network (or logical or IP), e.g. 192.168.1.3

Physical (or MAC or Data link or Hardware, e.g. 07:01:02:01:2C:4B)

2.3 Performance

Throughput: rate at which receiver receives real (or useful) data

Delay:

Propagation = Distance [m] / Velocity [m/s]

Transmission = DataSize [b] / DataRate [b/s]

Queuing: time spent in queues at computers

Processing: time computers spend processing data

Speed of light: 3×10^8 m/s

3 Data Transmission and Media

3.1 Signals

$$s(t) = A \sin(2\pi ft + \phi)$$

$$T = 1/f$$

$$\lambda = v/f$$

Spectrum is range of frequencies in a signal (or system)

Bandwidth is difference between maximum frequency component and minimum frequency component (sometimes practical limits)

3.2 Capacity

Nyquist bandwidth: $C = 2B \log_2(M)$

Shannon capacity: $C = B \log_2(1+SNR)$

$SNR = SignalPower/NoisePower$

$SNR_{dB} = 10 \log_{10}(SNR)$

3.3 Propagation

$$\text{Antenna gain: } G = \frac{4\pi A}{\lambda^2}$$

Free-space propagation:

$$\frac{P_t}{P_r} = \frac{(4\pi d)^2}{G_t G_r \lambda^2}$$

4 Signal Encoding Techniques

4.1 Digital Data on Digital Signals

Non-Return to Zero Level (NRZ-L)

0 = high level

1 = low level

Non-Return to Zero Invert on Ones (NRZI)

0 = no transition at beginning of bit interval

1 = transition at beginning of bit interval

Other schemes

See the lecture notes and make sure you understand them!

4.2 Digital Data on Analog Signals

Vary the Amplitude, Frequency or Phase of the waveform to represent different sequences of bits.

- Amplitude Shift Keying (ASK)
- Frequency Shift Keying (FSK)
- Phase Shift Keying (PSK)

Can use two levels (e.g. Binary FSK) or multiple levels. Can also combine the three to create multiple levels. Each level represents a sequence of bits.

4.3 Analog Data on Digital Signals

Convert the Analog Data into Digital Data, and then send on Digital Signal using encoding schemes like NRZ, ...

Sampling theorem: must sample at a rate two times the highest signal frequency

Analog to Digital data conversion using Pulse Code Modulation (PCM)

- Measure the signal at each time instant (according to sampling rate)
- Map the measured value into an integer value
- Map the integer value into a binary value
- The resulting binary sequence is the digital data

4.4 Analog Data on Analog Signals

Often want to send the analog signal at different frequency to analog data. Therefore modulation the analog data using Amplitude, Frequency or Phase Modulation.

5 Digital Data Communications

5.1 Error Detection

Add extra information to data – called the error detecting code.

Receiver uses the error detecting code to try to detect errors.

Single bit odd parity check: transmitter adds 1-bit to the front of data so that total bits has odd number of 1's. Receiver counts number of 1's – if odd, then assume no error. If even, then assume error.

Single bit even parity check: transmitter adds 1-bit to the front of data so that total bits has even number of 1's. Receiver counts number of 1's – if even, then assume no error. If odd, then assume error.

CRC: see lecture notes.

5.2 Error Correction

Also called forward error correction (FEC)
Transmitter sends redundant information; receiver uses it to try to detect and correct errors.

Hamming Distance: number of bits that differ in two sequences of bits.

Example error correction code using Hamming – see lecture notes.

6 Data Link Control Protocols

6.1 Flow Control

Aim: prevent sender from sending too fast for receiver.

Stop and Wait Flow Control: sender can only send next frame, once it has received ACK for previous frame.

Efficiency depends on propagation and transmission time: in general, if propagation is larger than transmission, then inefficient.

Sliding Window Flow Control: sender can send W frames before waiting for ACK.

- Each frame has sequence number: 0 to $2^k - 1$
- Maximum size of W is $2^k - 1$
- k is the number of bits available in the frame to store the sequence number

7 Topics Not Covered in Mid Term

The following topics are NOT covered in the mid-term:

- The specific frequency ranges of different systems e.g. Slide 4 of Transmission Media lecture
- Technical details like frequency, loss per km of guided media, e.g. Slide 8 of Transmission Media.
- Analog Data on Analog Signalling, e.g. AM, FM, PM
- Asynchronous and Synchronous Transmission from Digital Data Communication Techniques lecture
- Error Control (ARQ) from the Data Link Control Protocols lecture.